


HP10UV ELECTRICAL DIAGRAM



ILLUSTRATION

BAT1	BATTERY
BAT2	BATTERY
ST	STARTER
IG	IGNITION
HI	HIGH
LO	LOWER
TL	TAIL
R	RIGHT
L	LEFT
W	WINKER
E	EARTH

WIRE COLOR

PU	PURPLE
B	BLACK
Y	YELLOW
L	BLUE
G	GREEN
R	RED
W	WHITE
BR	BROWN
O	ORANGE
LB	LIGHT BLUE
LG	LIGHT GREEN
P	PINK
GR	GRAY

WINKER SW.

W	R	L
R	O	
N	O	
L	O	

HORN SW.

HO	BAT

DIMMER & SEAT OPEN SW.

HL	LO	HI	B1	B2
Lo	O	O	O	O
(N)	O	O	O	O
HI	O	O	O	O
SEAT OPEN	O	O	O	O

COMB. SW.

BAT2	IG	BAT1
O	O	O
O	O	O
O	O	O
O	O	O
LOCK	OFF	ON
O	O	O

LIGHT SW.

HL	CI	TL	RE
O	O	O	O
OFF	O	O	O
(N)	O	O	O
P	O	O	O
(N)	O	O	O
H	O	O	O

START SW.

FREE	ST	E
O	O	O
PUSH	O	O